

Miss WORLD '96

©1996 COMAD INDUSTRY CO., LTD. ALL RIGHTS RESERVED

FEATURES

- 1 or 2 players interactive
- New horizontal kit
- Continuation
- 1 or 2 players clear 80% or more of the girl, then show the exciting 50 Miss World Models.
- Miss World '96 has 3 different versions A, B and C for nude level.
"A" means very hot nude, "B" is normal and "C" is in clothes.
- 100% clear, poker game bonus!

PIN ASSIGNMENT

SOLDER SIDE		COMPONENT SIDE
GROUND	1	GROUND
GROUND	2	GROUND
+5V	3	+5V
+5V	4	+5V
	5	
+12V	6	+12V
KEY	7	KEY
	8	
	9	
SPEAKER(-)	10	SPEAKER(+)
	11	
VIDEO GREEN	12	VIDEO RED
VIDEO SYNC	13	VIDEO BLUE
SERVICE SW	14	VIDEO GROUND
	15	
COIN SW 2	16	COIN SW 1
2P START	17	1P START
2P UP	18	1P UP
2P DOWN	19	1P DOWN
2P LEFT	20	1P LEFT
2P RIGHT	21	1P RIGHT
2P PUSH BUTTON	22	1P PUSH BUTTON
	23	
	24	
	25	
	26	
GROUND	27	GROUND
GROUND	28	GROUND

DIP SWITCH SETTINGS

DIP SWITCH A

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
	Default Setting	OFF	OFF						
Test-Mode	Test-mode			ON					
Coin-1P	1Coin 1Play				OFF	OFF	OFF		
	2Coin 1Play				OFF	ON	OFF		
	1Coin 2Play				OFF	OFF	ON		
	1Coin 6Play				OFF	ON	ON		
	2Coin 1Play				ON	ON	OFF	ON	
	1Coin 3Play				ON	OFF	ON		
	1Coin 4Play				ON	ON	ON		
Coin-2P	1Coin 1Play				OFF			OFF	OFF
	2Coin 1Play				OFF			ON	OFF
	1Coin 2Play				OFF			OFF	ON
	1Coin 6Play				OFF			ON	ON
	2Coin 1Play				ON			ON	OFF
	1Coin 3Play				ON			OFF	ON
	1Coin 4Play				ON			ON	ON

DIP SWITCH B

ITEM	DESCRIPTION	1	2	3	4	5	6	7	8
Difficulty	Normal	OFF	OFF						
	Easy	ON	OFF						
	Difficult	OFF	ON						
	Very difficult	ON	ON						
Draw a Diagonal				ON	OFF				
Players	3					OFF	OFF		
	4					ON	OFF		
	2					OFF	ON		
	5					ON	ON		
Music in DEMO	ON							OFF	
	OFF							ON	
Option switch								-	OFF
									ON